Bluetooth Headset


Model: A3

Thank you for choosing the A3 Bluetooth Headset. Please read this manual carefully for future reference. If you have any further assistance, please connect our customer support team via e-mail behind this manual.

Package Content

 $\begin{array}{l} 1 \times \text{Bluetooth Headset} \\ 1 \times \text{USB Charging Cable} \\ 6 \times \text{Ear Buds(two are already installed)} \\ 1 \times \text{User Guide} \end{array}$

Package Diagram



- 1. Multifunction Button(MFB)
- 2. Volume / Previous Track Button
- 3. Volume + / Next Track Button
- 4. LED Indicator

Control Functions

Power On / Off	Press and hold the MFB for 3 seconds
Pairing	Power on until the LED Indicator flashes red and blue
	alternately
Play / Pause	Press the MFB once to play/pause.
Volume Increase / Decrease	Press the Volume + / Volume - Button once to
	play/pause.

Next / Previous Track	Press and hold the Volume + / Volume - Button for 2 seconds
Answer Phone Call	When a call is incoming, press the MFB once
Hang Up Phone Call	During a call, press the MFB once
Reject Phone Call	When a call is incoming, press and hold the MFB for 2 seconds
Redial	Press the MFB twice to re-dial the latest phone number
Activate Voice Control	Press and hold the MFB for 2 seconds
Clear Pairing History	Press and hold the Volume + button and Volume – button for 5 seconds until the LED Indicator flashes red once

Note:

When a call is coming, there is vibration promoted.

Specification

Bluetooth Version	CSR8635 V4.1
Bluetooth File	Support HSP, HFP.A2DP, AVRCP
Audio Codec	SBC , MP3, AAC, Faststream decoder
Range	33 ft / 10m
Waterproof Rating	IPX5
Charging Power	DC 5V
Working Time	10H at 70% volume
Charging Time	5V 80mA about1.5H2.5 H
Dimension	400*17*10mm
Weight	44g

LED Indicators

LED Indicator	Status
Red LED on	Charging
Blue LED on	Fully charged
Flashes blue and red	In Pairing mode
Flashes blue twice every 6seconds	Paired with a Bluetooth device
Slowly flashes red	Low battery

Note:

The earphones will not automatically connect to a *Bluetooth®* device when switched on, please read the next section on how to connect to your *Bluetooth®* device.

How to Use

1. Charging

- 1) Connect the charging port with any USB charging adapter or active computer USB port.
- 2) Charging will start automatically with the LED indicator turning red.
- 3) The earphones are fully charged when the LED indicator turns blue.

2. Pairing

- 1) Make sure the earphones and your *Bluetooth* @ device are next to each other (within 3 feet / 1 meter).
- 2) Press and hold the Multifunction Button for 5 seconds to bring the earphones into pairing mode with the LED indicator flashing blue and red.
- Activate the *Bluetooth®* function on your phone and search for nearby *Bluetooth®* connections:
 - For iOS: Settings > Bluetooth > On
 - For Android: Settings >Bluetooth: On > Scan for devices
- 4) Find "A3" in the search results. Tap on the name to connect. Once connected, the blue LED will flash twice every 5 seconds.

Note:

- If a PIN code is required for pairing, try "0000" (four zeroes).
- The Bluetooth earphones can remember previously paired devices.

3. Pairing with two devices at the same time


Although you can pair with two devices, only one of them can play music or make phone calls with the headphone at any time. To pair with two devices:

1) Follow the previous instructions in the "Pairing" section to pair the A3 with your first device.

- 2) Turn off the *Bluetooth®* function of your first device and follow the "Pairing" instructions again to pair and connect to your second device.
- 3) With the *Bluetooth®* function on both devices turned on, switch between the two paired devices by pausing the music on the first device and playing music on the second device.

4. How to Wear

Please wear the earphones as shown in the diagram:



Note:

- Please note the "L" and "R" markings on the earphones, they correspond to your left side and right side respectively.
- In addition to the earphones, two extra pairs of different sized ear buds are included in the package. Please try them out and find the most comfortable fit for you.

Troubleshooting

Q: My earphones will not switch on.

A: Please recharge it and make sure it has enough power. Plug the unit to a charger and see if the power button becomes solid red.

Q: Why can't I pair the earphones with other *Bluetooth®* devices?

A: Please check the following points:

- Make sure your *Bluetooth* ® device supports A2DP.
- Make sure the earphones and your device are next to each other or within 3 feet / 1 meter.
- You must get the earphones into pairing mode with the indicator flashing blue and red.
- Try to reboot your *Bluetooth®* device.

Q: After connecting and pairing with my *Bluetooth®* device, I cannot hear any

music from the earphones.

A: Please check the following:

• Your sound system is connected to the earphones (if the LED indicator flashes

blue once every 5 seconds, then they are connected).

- Make sure the music volume is at audible level on both your *Bluetooth®* device and earphones.
- Make sure your *Bluetooth* ® device is playing music.

Care and Maintenance

- Charge the earphones at least once every 6 months.
- Keep the earphones away from heat and humidity.

- Do not put the product under direct sunlight or hot areas. High temperatures will shorten the lifespan of the earphones and its battery.
- Do not try to take the product apart.
- Do not drop or knock your earphones on hard surfaces.
- Do not use chemicals or detergents to clean the product.
- Do not scrape the surface with sharp objects.

Warranty

TaoTronics earphones are covered by the TaoTronics Parts and Labor Warranty for

12 months from the date of their original purchase. If the device becomes defective, please contact TaoTronics Support to launch warranty claim. We will instruct you on how to return the defective unit back to us for repair and replacement.

The following are excluded from the TaoTronics warranty:

- Device purchased as 2nd hand, used or from unauthorized sellers
- Damage resulted from misuse and abusive action
- Damage resulted from chemical, fire, radioactive substance, poison, liquid
- Damage resulted from natural disaster
- Damage caused to any 3rd party / person / object and beyond

No return will be accepted without seller authorization.

Statement

We can only provide after sale services for products that are sold by Richen or

Richen authorized retailer and distributor. If you have purchased your unit from a

different place, please contact the seller for return and warranty issues.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the

receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.